



PAPERSYSTEMS

BANDING "EZ-BULK"



Banding Placement

Band "EZ-BULK" four times total, two bands each direction vertically. Use the edge protectors provided. Make sure the banding placement is as shown in the photo.



Step 1

Loop your plastic banding through the buckle



Step 2

Form a loop with the plastic banding and slide onto the metal buckle



Step 3

Loop both sides of the buckle



Step 4

While squeezing the handle of the tensioner down slide the banding underneath the three metal spools



Step 5

Release and place the loose banding through the first two metal spools



Step 6

Ratchet the handle in an upward and downward motion to tighten the bands. Allow enough banding slack (8-12") so you are able to ratchet the buckle tight.



Step 7

Once the buckle is compressed and the banding is tight squeeze down on the handle and cut off the excess banding



Finished

Band the container four times total to the pallet, two bands each direction vertically. Front two bands go through the fork entry of the pallet. The side bands between the middle deck boards