



# PAPERSYSTEMS

## EZ-Bulk 48x40 2" Corner Evacuation/ Vertical Fill



**Step 1**

Once the container is assembled and positioned on the pallet you are ready to install your liner. Hang the liner from the fill fixture provided.



**Step 2**

Locate and lock your top fill fitment into the fill bridge. Make sure the key hole knock out is positioned facing away from the bottom evacuation.



**Step 3**

Reach through the evacuation hole on the body and pull the fitment through with your hand.



**Step 4**

Lock in your bottom evacuation fitment with the collar provided. Make sure the timing mark on the fitment is in the 12 o'clock position.



**Step 5**

Begin filling and allow roughly 3-4 inches of product to enter the liner, then gently pull on the four corners of the liner so all four corners are up. This will help seat the liner. Once the tote is half filled adjust the liner again.



**Step 6**

Fill the container to the top leaving roughly 1/2" space from the top edge. Never stack under-filled containers.