



# PAPERSYSTEMS

## EXO-BIN COLLAPSIBLE & RETURNABLE



**Arrival**

“EXO-BIN” arrives knocked down flat with all component parts nested in the base.



**Step 1**

Begin by inserting all twelve poles vertically into the base/ pallet of the “EXO-BIN” Make sure all poles are fully inserted into the base. You may use a rubber mallet to reinforce the poles.



**Step 2**

Install the polypropylene side wall sack. Secure sack with your corner poles.



**Step 3**

Make sure the bottom evacuation hole lines up with the evacuation in the base pallet.



**Step 4**

Open the polypropylene side wall sack. Lift up and insert your corner poles into the holes at the bottom of the sack. Only your corner posts are exposed on the inside of the sack.



**Step 5**

Once the sack is in place you are ready to install your top hoop. Gently lay the top hoop on all twelve poles. Gently shake the hoop so it falls into place on the twelve upright poles.



**Step 6**

Use the plastic collar provided to lock in the bottom evacuation fitment.



**Step 7**

Once the top hoop is secured in place and the evacuation fitment is locked in, you may begin filling. (See filling instructions.)



**Finished**

Band the container to the pallet 4 times total; 2 bands each direction vertically.. Use 5/8” poly-nylon banding with a 1400 lb breaking strength or the composite plastic equivalent.

1-800-342-2855  
WWW.PAPER-SYSTEMS.COM

515-280-1111  
Contact us today!!!

515-280-9219 (FAX)  
psi@paper-systems.com