



PAPER SYSTEMS

BANDING EZ-SET



Step 1

Use a 5/8" polyester banding with a 1400 lb breaking strength or a 3/4" steel with a .022 strength.



Step 2

Band EZ-SET the (40") short side first.



Step 3

The banding placement is also marked on the lid of the container.



Step 4

Thread the banding through the pallet.



Step 5

Thread the banding through the middle of the pallet between the bottom deck boards. Never apply banding through the pallet fork pockets.



Step 6

Line up the banding with the print pattern on the lid.



Step 7

Keep the banding straight and Uniform.



Step 8

Use the automatic bander to tighten the banding.
Make sure the banding is "fiddle string" tight. Do not overtighten and crush the lid.



Finished

Band the container four times total, two bands each direction vertically. Fully insert the forks to move the EZ-SET Container. Make sure the container is banded prior to moving around the facility.

1-800-342-2855
515-280-9219 (FAX)

Contact us today!!!