



PAPERSYSTEMS

EZ-BULK BOTTOM PAD ASSEMBLY



Step 1

The "EZ-BULK" bottom pad will arrive knocked down flat.



Step 2

Use a clean flat surface to begin folding the integrated locking bottom pad. You may use the body of the "EZ-BULK" as a work station. Fold the first panel up and inward along the score line.



Step 3

Fold the die cut tab through the die cut slot as shown.



Step 4

The die cut tab locks into position through the die cut slot. Repeat the process on all eight sides of the bottom pad. Rotate the pad in one direction as you lock the tabs in place.



Step 5

This is an inside view of a completed panel locked into place.



Step 6

This is the completed bottom pad.