



PAPERSYSTEMS

EZ-BULK LID ASSEMBLY



Step 1

“EZ-BULK” lid will arrive completely flat.



Step 2

Using the body of the container as a table, begin folding the lid. Assemble the lid, using the score lines as a guide, to tuck and fold the edges of the lid. Rotate the lid as you tuck fold.



Step 3

Tuck and fold edges next to die cut notch. Do not overlap the cardboard folds as this will make the lid too tight for installation later.



Step 4

When you come to the last edge, fold in the point and tuck under the remaining flap.



Step 5

Completed Lid



Step 6

Once the container is filled with product, you are ready to place the lid on the container.