

Standard “EZ-BULK” Assembly

CALL TODAY & SAVE (800) 342-2855

WWW.PAPER-SYSTEMS.COM



STEP 1

EZ-BULK arrives knocked down flat. The lid is pre-formed and the liner is preinstalled in the bottom pad. The lid, bottom, pad, and liner are referred to as the cartridge.



STEP 2

Use the pallet as a force of resistance to help form the octagon base.



STEP 3

Position the body of the container on the pallet. Make sure the evacuation hole is over the corner of the pallet.



STEP 4

Nest the bottom cartridge with pre-installed liner into the octagonal body. Line up the bottom evacuation with the evacuation hole on the body.



STEP 5

Hang the liner from the fill bridge. Lock in top fill fitment into fill bridge. You are now ready to begin filling.



STEP 6

Band the container to the pallet 4 times total; 2 bands each direction vertically. This is marked on the lid of the EZ-Bulk. **MUST** use 3/4" steel banding or equivalent. Use edge protectors.