

2" BSP Valve System & Plunger Cutter



- 1.** Remove the 2" screw cap from the bottom 2" flange of the bag liner and attach the valve into the 2" bottom evacuation fitment.



- 2.** Thread the valve assembly into the 2" bottom evacuation fitment. Note: It is very important to thread the valve assembly all the way to make sure the o-ring is seated and sealed against the evacuation fitment.



- 3.** Attached the plunger cutter directly to the valve and turn the yellow handle to the open position. Once the valve is open you are ready to puncture the membrane on the liner.



- 4.** Close Valve and remove plunger cutter. You are now ready to connect to your hose for pumping