

"EZ-VALVE" Evacuation Valve Instructions



1

Locate "EZ-VALVE" on bottom side of "EZ-DRAIN" or "EZ-BULK" container system.



2

Remove 1 1/2" cap and thread in a standard outbound 1 1/2" female NPT connector or adapter as needed.



3

Remove safety tie strap. When ready to drain, lift locking finger and push "EZ-VALVE" body in to initiate flow. Side profile of valve assembly shown here for reference. Then use locking finger to secure "EZ-VALVE" in the open position for continuous evacuation. To stop flow, pull EZ-VALVE out and return the valve to the closed position. **Note: Make sure to support or brace "EZ-VALVE" at all times and keep protected from trauma and or abuse.**

**PAPERSYSTEMS**

P.O. BOX 6188
321 SW 4TH STREET
DES MOINES, IA 50309, USA

TF: **(800) 342-2855**
LOCAL: (515) 280-1111
FAX: (515) 280-9219

paper-systems.com