



# PAPER SYSTEMS

## FDA 2" Valve With Disposable Ring Cutter



# 1

Remove the 2" screw cap from the bottom 2" flange on the bag liner.



# 2

Make sure the valve is in the off position. The valve handle will be at a right angle (perpendicular) to the valve body.



# 3

Take disposable ring cutter out of the evacuation fitment and turn the cutter around so the teeth are facing in (facing the membrane). Gently re-insert the cutter into the 2" evacuation.



# 4

Thread the 2" ball valve assembly into the bottom 2" evacuation fitment. As the valve assembly is threaded into place, the increased thread engagement will cause the disposable cutter to pierce the membrane. **Note: It is very important to thread the valve assembly all the way in to make sure the o-ring is seated and sealed against the evacuation fitment.**



# 5

The valve is ready to connect to the outbound couplings to drain the liquid contents. **Note: Support the valve assembly at all times and keep protected from trauma and or abuse.**

1-800-342-2855

[WWW.PAPER-SYSTEMS.COM](http://WWW.PAPER-SYSTEMS.COM)